

ESPECIFICAÇÕES

TECLADOS

Superior: 44 Teclas
Inferior: 44 Teclas
Pedaleira 13 Teclas

REGISTRAÇÕES

Superior:
(Upper keyboard)

Flute 16'
Flute 8'
Flute 5 1/3'
Flute 4'
Flute 2 2/3'
Flute 2'
Trombone 16''
Clarinet 16'
Trumpet 8'
Oboé 8'
String 16'
String 8'
String 4'

Inferior:
(Lower keyboard)

Flute 8'
Flute 4'
Diapason 8'
Horn 8'
Cello 8'
Cello 4'

Pedaleira:
(Pedal)

Bass 16'
Bass 8'
Tuba 16'

PRESET
(upper preset)

Piano
Harpsichord
Guitar
Banjo
Mandolin
Vibraphone
Accordion
Cancel

PERCUSSION:

Attack 4'
Attack 2 2/3'
Attack 2'
Decay

ORCHESTRAL

MINAMI

Upper Flute
Upper Orchestra
Lower
Preset
Celeste/coro sinfônico

SUSTAIN

Upper
Lower
Pedal

VIBRATO

Depth
Speed
Decay

RITMOS

Seletores de Ritmos:

Waltz Rhumba
Slow-Rock Cha-cha
Fox-Trot Tango
Swing March
Rock Bossa-nova
Disco Samba

Controle de Variação (Break)

Volume
Tempo
Grave (Bass)
Agudo (Treble)
Liga desliga Manual (Synchro)
Liga desliga Pedal (Pé)
Indicador de Tempo (Down Beat)

PROGRAM ARPEJO,

BASS, CHORD

Touch - Avanço Manual
Finger Chord - One finger chord
Memory Eletro Chord - Arpejo
Alternate Eletro Bass- Walking
Eletro Bass Memory Eletro Bass

ELECTRO BASS

Bass 16'
Bass 8'
Sustain

ELECTRO CHORD

Piano
Guitar
Sustain

ARPEJOS

Arp I
Arp II
Sustain

CONTROLES

Volume Geral
Volume Preset
Manual Balance
Agudo
Upper Attack
Pedal de Expressão
Led Indicador de Força
Chave Liga-Desliga
Entrada Auxiliar
Saída Auxiliar
Fusível de Proteção
Chave de Seletora de Voltagem
Entrada para fone de ouvido

ESPECIFICAÇÕES TÉCNICAS

Entrada de força: 110-120-220-240 V
Potência de saída: 40w (rms)
Falantes: 2 woofers 12'
1 Tweeter 4'

Peso: 80kgs
Comprimento 1,10m
Largura - 60cm
Altura - 96,5cm